
General Notes

- 1. Temporary Loops are to be provided by the homeowner, electrician, contractor, etc.
- 2. There needs to be at least 18 inches of conductor out of the weatherhead.
- 3. Minimum wire size is #4 copper conductor or #2 aluminum.
- 4. All connections need to be made in rain tight boxes.
- 5. All conductors must be in conduit and secured to the post.
- 6. Clearance for the overhead conductor must be at least 18' if crossing an area susceptible to truck traffic.
- 7. The temporary loop must be set within 15' of an MJM pole.
- 8. MJM will provide conductor and wedge clamp for connection at weatherhead.
- 9. The member is responsible for installing a temporary ground rod for the service.
- 10. Meter base needs to meet National Electric Code.





Overhead Temporary Service Installation
Single Phase 120/240 Volts